



UNDERSTANDING SHELVING

BASICS

Starters include two finished end panels, with connecting holes on the inside only.

Adders include only one upright panel, with connecting holes on both sides.

Note: Backs and Partitions (optional) must be ordered separately. Backs are used with single-sided shelving; Partitions are used with double-sided shelving.


ORDERING

For a single bookshelf, order a single Starter to use by itself.

For a row of shelving, order one Starter and as many Adders as needed to complete your desired row length.

ASSEMBLY


1. Place Starter unit at the beginning of your row.
2. Remove the end panel on the side where your first Adder will be placed. Put this panel aside.
3. Connect the Adder to the open-ended Starter.
4. Continue connecting more Adders until you attain your desired configuration.
5. At the end of the last Adder, connect the end panel that was previously removed from your Starter. One finished Starter end panel will be at the left end of your row of shelving, and the other finished Starter end panel will be on the right end of your row of shelving.





SHELVING ASSEMBLY DETAILS


1. Place Starter end panel with shelves on the left edge of your row of shelving.



2. Remove right Starter end panel and put it aside.



3. Attach Adder to the right side of your Starter.



4. Attach as many more Adders as needed.



5. Attach right Starter end panel (removed in Step 2) to the right side of your last Adder.



Notes:

- The diagram above shows the procedure for building a row of shelving from left to right; follow the same procedure in reverse when building from right to left (i.e., Place Starter end panel with shelves on the *right* edge of your row of shelving... etc.).
- This procedure applies to both single-sided and double-sided shelving.